

No-Idle Bunk Comfort | Save Money While You Sleep!

The Heater Of Choice By Drivers World-Wide

Webasto Air Heaters:

Provide rapid cab heat without idling

 Save thousands of dollars a year in fuel - use as little as 1 Gallon of fuel in 22 hours

 CARB approved and EPA SmartWay verified

Quiet operation ensures a restful night's sleep

Full diagnostics with PC interface available

7,000 - 13,650 BTU/h heat output







Fewer Emissions
Cleaner, better for
the environment



More Consistent Heat
Allows drivers to rest

Allows drivers to rest more comfortably



More EfficientConsumes less fuel



Higher Install FlexibilityMore Installation Options



Costs less to operate & maintain over the life of the heater

ber 909561 • 10/16 • Errors and omissions excepted • Printed in USA • © Webasto Thermo & Comfort North America, Inc. 2016

Technical Specifications

	Air Top 2000 ST
Heating Capacity	3,100 – 7,000 BTU/h <i>(0.9 – 2.0 kW)</i>
Fuel	Diesel #1, Diesel #2, Arctic, Biodiesel B5 & B20
Fuel Consumption	0.03 – 0.06 gal/h (0.12 – 0.24 l/h)
Rated Voltage	12 or 24 V
Operating Voltage Range	10.5 – 16 or 21 – 32 V
Rated Input	1.25 – 2.45 Amps (14 – 29 Watts)
Air Flow	37 cfm (63 m³/h)
Dimensions (L x W x H)	12.25 x 4.78 x 4.85 in <i>(311 x 120 x 121 mm)</i>
Weight	5.73 lbs (2.6 kg)

Available Air Top 2000 ST Heater Kits:

Air Top 2000 ST Diesel Kit with Rheostat (12 V) - Part Number: 5001114A Air Top 2000 ST Diesel Kit with Rheostat (24 V) - Part Number: 5001314A Air Top 2000 ST Diesel Kit with SmarTemp 2.0 (12 V) - Part Number: 5010609B

Standard Kit Components:


- Integrated Control Unit
- On/Off Switch with Variable Temperature Control
- Fuel Metering Pump w/Mounting Bracket
- Fuel Line and Fuel Filter
- Universal Fuel Standpipe
- Heater Mounting Bracket w/Gasket
- Wiring Harness w/Fuse Holder
- Exhaust Tubing
- Combustion Air Tubing and Heater Ducting
- Air Inlet/Outlet Vent
- Operation/Installation Manual
- 2 Year/2000 Hour Limited Warranty

Optional Accessories:

SmarTemp Control 2.0 Retrofit Kit (with Harness) - Part Number: 5010628B

Remote Temperature Sensor - Part Number: 1319842A

System Schematic



- 1. Air Top 2000 ST Heater
- 2. Control Dial
- 3. Cold Air Inlet
- 4. Hot Air Outlet/Ducting
- 5. Combustion Air Inlet
- 6. Exhaust Outlet
- 7. Fuel Metering Pump
- 8. Fuel Filter
- 9. Fuel Standpipe

SmarTemp Control 2.0 (optional):

for Air Top 2000 ST - Part Number 5010628B



- Programmable heater start time
- Ergonomical design
- Large backlit LCD screen
- Ambient temperature display

Webasto Thermo & Comfort North America, Inc.

15083 North Road Fenton, Michigan 48430

USA

Toll Free: 800-860-7866 Phone: 810-593-6000