

PERFORMANCE SPECIFICATIONS

SUPRA® 960

Supra 960 unit delivers superior reliability, capacity, and airflow to ensure maximum protection and the highest cargo quality.

Supra 960 unit's total flexibility means virtually any setpoint on any truck body size.

 Heavy-duty, high-displacement engine and compressor run slower for longer life and lower operating costs.

- Extended service intervals for maximum asset utilization.
- Sleek, attractive composite skins are lightweight, damageresistant, and easy to clean.
- Powerful optional electric standby motor offers superior performance and longer operating life.

Accessories and Options:

Battery (dealer-supplied)
Battery box
30-gallon fuel tank
50-gallon fuel tank
Fuel heater
Top debris protection grille
High-voltage electric standby
460v-3ph-60Hz
Supply-air control
Stealth Noise Reduction kit
Open door shutdown switch
Heavy-duty electric standby motor:
208v/230v-3ph-60Hz
or 220v-3ph-50Hz
Data Trak

Remote Control Panel



Condenser Dimensions

78.5" x 37.0" x 27.5" (1,995 x 940 x 699 mm)

Evaporator Dimensions

48.2" x 28.8" x 13.0" (1,225 x 732 x 330 mm)

Body Opening

49.0" x 13.8" (1,245 x 350 mm)

Approximate Weights:

TDB-36: 1,250 lb (567 kg) without standby TDS-36: 1,300 lb (590 kg) with standby

Cooling/Temperature Capacity: Ambient at 100°F (38°C) Speed: 2,250 rpm diesel/60-hertz electric operation

Evaporator Return Air Temp.	Diesel Operation		Standby Operation	
	Btuh	Watts	Btuh	Watts
35°F (2°C) 0°F (-18°C) -20°F (-29°C)	32,000 20,000 12,500	9,380 5,860 3,665	31,000 20,000 12,500	9,085 5,860 3,665

Standard Features Include:

CT3-69 TriVortex diesel engine 05G 37CID 6-cylinder compressor Automatic hot-gas heating system Refrigerant R-404A

Three-way refrigeration valve system Standard with electric standby

Remote-mount power receptacle Microprocessor control system

Cab Command™remote control center Critical Cargo Monitor (in cab) Audible temperature alarm (in cab) Red light visual warning alarm (in cab) Automatic pretrip system

Lighted Cab Command keys Main on/off system power switch

Display indicators

Cool-Heat-Defrost Start/Stop-Out of Range

Engine Operation-Electric Standby

Digital readout

Cab Command (in cab)
Engine coolant temperature

Unit suction pressure

Battery voltage

Engine run hours

Electric standby hours (if equipped)

Maintenance interval hours

Total on-time hours

Setpoint temperature

Box return-air temperature

Standard Features (continued):

Automatic Start/Stop fuel saver
City Speed control
Automatic defrost control
Extended-life antifreeze
High coolant temperature protection
High-power 105-amp alternator
Heavy-duty dry air cleaner
Spin-on fuel and lube filters
Low engine oil protection
High refrigerant pressure protection
Low refrigerant pressure protection
Receiver tank pressure relief
Bottom panel
Installation package

stallation package Electric fuel pump Fuel lines

Battery cables
Installation hardware
Fuel tank pickup tubes

Specifications are subject to change without notice.

Warranty: Product warranty and limitations are outlined in Form 62-10857.

This warranty applicable only in North America. Consult your Carrier Transicold representative for warranty coverage elsewhere. Form 62-11687 Rev B.

North America

Carrier Transicold 700 Olympic Drive Athens, GA 30601 USA Central America and Mexico

Carrier Transicold Ejercito Nacional 253-A Piso 5 Colonia Anahuac 11320 Mexico D.F.

